






















Feeder Pallet	MFU65 II	Smart setup station	Extension feeder	On-machine feeder set stand	Reel Setting Stand
	 Unified feeder pallet cart	 Rewinds multiple reels at once and provides guidance for where to set feeder pallets	 Feeder setting stand that is attached to a feeder pallet	 This is a feeder setting stand which is attached externally to the machine and can be folded up.	
NXT III / IIIc   M3 M6	AIMEX III / IIIc	NXT III / IIIc   M3 M6   AIMEX III / IIIc	NXT III / IIIc   AIMEX III / IIIc	AIMEX III / IIIc	NXT III / IIIc   AIMEX III / IIIc














Auto Splicing Unit	Splicing stand	Auto Feeder Maintenance Unit	Fuji Intelligent Feeder Inspection Jig	PCU II	Tray unit-M Change Unit
		 Automates cleaning, lubricating and checking the tape indexing position for feeders.	 An inspection jig for the upkeep of feeders.	 A dedicated device used to change feeder pallets	
NXT III / IIIc   AIMEX III / IIIc	NXT III / IIIc   AIMEX III / IIIc	NXT III / IIIc   AIMEX III / IIIc	NXT III / IIIc   AIMEX III / IIIc	NXT III / IIIc   M3 M6	NXT III / IIIc   M6

PSU	Feeder Stand
 Unit for storing feeder pallets	
NXT III / IIIc   M3 M6	NXT III / IIIc   AIMEX III / IIIc

# NXT series / AIMEX series Device units



Tape feeder				Tray unit					Tray feeder		
<b>Fuji Intelligent Feeder</b>	<b>Fuji intelligent feeder that supports cut strip tape<sup>*1</sup></b>	<b>Auto Loading Feeder</b>	<b>Radial tape feeder</b>	<b>Tray unit-LT2</b>	<b>Tray unit-LTC</b>	<b>Tray unit-LTW2</b>	<b>Tray Unit-M</b>	<b>Inner tray stage</b>	<b>Stacked JEDEC tray feeder</b>	<b>Tray feeder-L</b>	<b>Tray feeder-M</b>
											
Supports 4 to 104 mm wide tape	Supports cut strip tape that is 12 to 88 mm wide and 80 mm or more long	Parts are automatically indexed to the pickup position just by inserting tape into the rear of the feeder	Supports radial tape parts	This unit is used in place of a feeder pallet	Has 19 feeder slots and a dip flux unit can be set	Allows for up to 48 tray parts and 25 8 mm tape feeders to be loaded at the same time	A tray part supply unit that can be loaded into a feeder pallet	JEDEC standard trays are loaded directly inside the machine	Used to supply one part type non-stop to the machine from stacked JEDEC standard trays	2 to 4 inch chip trays are supported as well as JEDEC trays	2 to 4 inch chip trays are supported
NXT III / IIIc   M3(SE) M6   AIMEX III / IIIc	NXT III / IIIc   M3(SE) M6   AIMEX III / IIIc	NXT III / IIIc   M3(SE) M6   AIMEX III / IIIc	NXT III / IIIc   M6   AIMEX III / IIIc	NXT III / IIIc   M6	NXT III / IIIc   M6	AIMEX III / IIIc	NXT III / IIIc   M6   AIMEX III / IIIc	AIMEX III	NXT III / IIIc   M6	NXT III / IIIc   M6   AIMEX III / IIIc	NXT III / IIIc   M3(SE) M6   AIMEX III / IIIc

Stick feeder			Dip flux unit				Reject parts conveyor				Glue check unit	
<b>Stacked stick feeder</b>	<b>Vibratory stick feeder</b>	<b>Single vibratory stick feeder</b>	<b>Rotary-type dip flux unit</b>	<b>Rotary-type dip flux unit plus</b>	<b>Rotary-type Dip Flux Unit (High Speed)</b>	<b>Bridge-type dip flux unit</b>	<b>Reject parts conveyor-L</b>	<b>Reject parts conveyor-1.5L</b>	<b>Reject parts conveyor-M</b>	<b>Reject parts conveyor-M (long type)</b>	<b>GCU</b>	<b>GCU2</b>
												
A unit in which sticks are stacked to allow for non-stop part supply	A unit for supplying various types of stick parts using vibration	A unit for supplying stick parts which are not free standing	A unit for transferring flux to bumped parts before placement	Supports varying bump sizes	Supports high-speed heads	The dip tank moves back and forth to create an even film thickness using a squeegee	Parts for which imaging errors occur are unloaded without being damaged	Supports 1.5 inch parts for OF heads		Used when two tray unit-Ms are loaded	Trial glue dot unit to measure glue dot diameters when using GL heads	Trial glue dot unit to measure glue dot diameters when the DX head and the glue tool are used
Applicable part size: 74 x 180 x 25.4 mm	Applicable part size: 74 x 180 x 38.1 mm	Applicable part size: 45 x 180 x 13 mm	Applicable part size: 45 x 180 x 13 mm				NXT III / IIIc   M3 M6   AIMEX III / IIIc	NXT III / IIIc   M6   AIMEX III / IIIc	NXT III / IIIc   M3 M6   AIMEX III / IIIc	NXT III / IIIc   M6	NXT III / IIIc   M3 M6	AIMEX III / IIIc

\*1 To support cut strip tape, modification of Fuji intelligent feeders is required.